


Document Camera Guide


To use the document camera

1. Login to PC
2. Turn projector on and select PC input
3. Double click desktop shortcut HoverCam Flex11



To rotate the image

Use the rotation button and wheel featured below



If you have any issues or concerns please contact the Support Desk at
513-558-6949 or Clermont.support@uc.edu